






CRANK CASE

No.	ID Zboží	Název	No.	ID Zboží	Název
1	380020070-0001	Hexagon shaft shoulder bolt	12	380850016-0001	Stay stud
2	120230118-0001	Cylinder head cover	13	380850010-0001	Stay stud
3	120250045-0001	Gasket for cylinder head cover	14	380180147-0001	Stud
4	270960046-0001	Spark plug	15	293030024-0001	Engine brake
5	110810363-0001	Crankcase body	16	381140582-0001	Tension spring
6	380650335-0001	Oil seal	17	380180210-0001	Stud
7	380140067-0003	Hexagon bolt with flange	18	380140100-0003	Hexagon bolt with flange
8	110840041-0001	CAP, BREATHER CHAMBER	19	110690125-0001	Oil rule combination
9	110850030-0002	PACKING, BREATHER CHAMBER			
10	140250026-0001	Leaf valve			
11	380140039-0003	Hexagon bolt with flange			




Crankcase cover

No.	ID Zboží	Název
1	380140103-0004	Hexagon bolt with flange
2	110820198-0001	Crankcase cover
3	380650347-0001	Oil seal
4	171630031-0001	Speed regulating arm
5	380450527-0001	Flat washer
6	380650338-0001	Oil seal
7	381350004-0001	Pin clip
8	380600241-0001	ocation pin
9	171750039-0001	Components of governor gear
10	380140167-0002	Hexagon bolt with flange




CRANKSHAFT/PISTON

No.	ID Zboží	Název
1	130070257-0001	Piston ring combination
2	130030303-0001	Piston
3	130060030-0001	Piston pin
4	380560055-0001	Steel cable baffle ring
5	130150142-0001	Connecting rod
6	130290672-0001	crankshaft
7	130230061-0001	Timing driving wheel




CAMSHAFT

No.	ID Zboží	Název
1	140450060-0001	Valve rocker combination
2	140710013-0002	Plate, push rod guide
3	140670028-0001	Push rod
4	140690021-0001	Lifter, Valve
5	140020174-0001	Camshaft assy
6	140380020-0001	Retainer, valve spring
7	140340039-0001	Inner spring of valve
8	140400016-0001	Valve oil seal
9	500550034-0001	Valve Kit




STARTER

No.	ID Zboží	Název
1	380330056-0001	Cap nut
2	193690028-0001	Starter decoration cover
3	160210165-0001	Fan cover comp.




CARBURETOR

No.	ID Zboží	Název
1	170430148-0001	Carburetor gasket
2	170440126-0001	Heat insulating pad for carburetor
3	170450006-0001	Heat insulating plate for carburetor
4	170021874-0001	Carburetor
5	170430177-0001	Carburetor gasket
6	173090001-0001	Locker of choke valve pull rob




FLYWHEEL/IGNITION COMP

No.	ID Zboží	Název
1	270920421-0001	COIL ASSY.,IGNNTION
2	380140103-0004	Hexagon bolt with flange
3	270020277-0002	FLYWHEEL COMP
4	380370051-0001	Hexagon nut with flange




AIR CLEANER

No.	ID Zboží	Název
1	180020894-0001	Air filter
2	180130178-0001	Air filter element
3	380370066-0001	Hexagon nut with flange
4	380741304-0002	Breather tube




CONTROL

No.	ID Zboží	Název
1	171650040-0001	Choke valve pull rod
2	171590041-0001	Throttle rod
3	171620033-0003	Speed regulating bracket
4	171600107-0001	Governing spring
5	171680164-0001	Throttle handle combination
6	380140167-0002	Hexagon bolt with flange
7	380930025-0001	Location wire nail




MUFFLER

No.	ID Zboží	Název
1	180660077-0001	Muffler gasket
2	180572242-0003	Muffler
3	180960204-0001	Muffler guard shield
4	380370048-0001	Hexagon nut with flange
5	171470012-0001	Control components of choke valve
6	380140167-0002	Hexagon bolt with flange



FUEL TANK		
No.	ID Zboží	Název
1	170490318-0001	Tank
2	170870094-0001	Tank cover
3	170010017-0001	Fuel filter
4	380140077-0005	Hexagon bolt with flange
5	380750234-0002	Oil tube
6	380950190-0001	Pipe clip



Components of starting motor

No.	ID Zboží	Název
1	270360144-0001	Components of starting motor
2	270810190-0001	Starting relay
3	270860070-0002	Mounting bracket for electric device
4	271110181-0001	Battery Box
5	270370048-0001	bundle of starting motor