



VeGA 4618 SXH 5in1

VeGA 4618 SXH		
No.	ID zboží	Název
1	5021041000063201B	blade tighten bolt
2	502105200010C	blade
3	5021051000220001N	motor centrifugal cutter
4	502105400015C	centrifugal cutter bush
5	50A26800300502	screw
6	502102300148A	driving belt wheel
7	502102600048C	triangle belt
8	50A26809003701	flat key
9	50A26800901901	block ring for axis
10	50A26800500801	hex locking nut
11	50A26800103701	self-driving screw
12	50A26800700701	flat ring
13	5021041001910001C	belt wheel protecting cover
14	50A26800100501	self-driving screw
15	5021041002970001A	front panel handle
16	5021041002950006A	head cover
17	5021041002960001A	cover board
18	5021011003670006B	wheel cover-1
19	50A26800502801	hex flange locking nut
20	502101300065A	bearing
21	5021011002660001A	wheel ass'y
22	50A26800706202	wave washer
23	50A26800611901	hex flange bolt
24	5021011001023201B	lower support of wheel axle
25	502101500077C	front wheel axle ass'y
26	5021011002893201B	upper support of wheel axle
27	50A26800500501	hexagonal locking nut
28	502109800134A	spring of front wheel axle
29	50A26800201901	tooth screw
30	502106200128A	wheel axle fixed ring
31	50A26800502401	locking screw
32	50A26800900201	open block ring
33	502104400013E	left output gear ass'y
34	50A26800705102	flat washer
35	50A26800402302	bearing
36	502102400156D	bearing sheath
37	50A26809000102	column pin
38	502102300058B	gear box
39	502104400014E	right output gear ass'y
40	50A26800611201	hexagon flange bolt
41	502102300154A	position fixing plate
42	502106200554C	position fixing board
43	502106200053N	side-discharge pos. shaft
44	50A26800800402	spring washer
45	50A26800201501	tooth screw
46	502109800066D	side cover board spring

No.	ID zboží	Název
47	5021061005340001A	sidedischarge cover board
48	5021041001313209C	sidedischarge protectcover
49	5021011000620006C	wheel cover-1
50	5021011001700001N	wheel ass'y
51	502101100081B	wheel gear ring
52	5021011003730001F	11" dust-proof wheel cover
53	502101500206A	rear wheel axle ass'y
54	50A26800900301	open block ring
55	502109200020A	adjusting washer
56	5021061003944017A	height adjustment board
57	5021062010010002A	deck
58	5021091000363200A	cable pressing bracket
59	502208100010A	cable pressing board
60	50A26800100302	self-driving screw
61	502106200818A	connecting rod
62	502106600013A	cable protecting sheath
63	502106200815A	handle ass'y
64	50A26800303301	screw
65	5021061002883047A	height adjustment ass'y
66	50A26800606401	hexagon flange bolt
67	5021062001660002B	right handle bracket
68	502109800072A	right knob spring
69	502106300028B	long rod
70	502109800071A	left knob spring
71	5021062001650002B	left handle bracket
72	50A26800304401	special bolt
73	50A26800612501	hex bolt
74	502109200029B	flat washer
75	5021041002120001A	wind sleeve(lower)
76	502011200066A	capacitor
77	5021041000103201A	motor locking bolt
78	50A26800801002	tooth locking washer
79	502050100062A	induction motor
80	5021081000173200N	motor fan
81	5021041002110001A	wind sleeve(upper)
82	5021041001760001B	right wind inlet board
83	5021041002320006A	motor cover
84	5021041001750001B	left wind inlet board
85	5021041002960001A	cover board
86	5021061000170001A	connecting wire protecting
87	50A26800600401	flat head bolt
88	5021061005660001A	pipe sleeve
89	5021061000020182B	lower handle knob
90	50A26800502301A	hex nut
91	5021061005670001A	sleeve bushing
92	5021061000013201A	cable clamp

No.	ID zboží	Název
93	5021061001543201N	lower adjustment gear
94	50A26800104902	self-driving screw
95	5021063003240001A	lower handle
96	50A26809004801A	column pin
97	5021061000270002A	locking handle
98	502109200025A	pressing plate
99	502109300026A	locking handle bolt
100	5021061001533201C	upper adjustment gear
101	50A26800612002	flat head bolt
102	502106800748A	driving cord ass'y
103	5021061000043201A	self-driving screw
104	50A26800700801	flat ring
105	50A26800501603A	cap nut
106	5021061004400001N	block ring
107	5021061001380001A	cable hook ring
108	502011100083N	power cord
109	5021061000223208A	cable sheath
110	502106900002A	connecting wire
111	5021061000160001A	connecting wire protecting
112	5021041002073201B	switch box(right)
113	5021061001560002B	switch button
114	502224200003A	spring of transfer board
115	502109100038A	cable pressing board
116	502011400013D	arc switch
117	5021041002063201N	left switch box
118	5021041002083201N	pressing board switch box
119	5021041004680001B	left handle support
120	5021061001643201A	cord connecting buckle
121	502106800260B	driving cord ass'y
122	5021041000980001B	right handle support
123	5021061001580002A	right handle plug-in
124	502106800004A	right plug-in spring
125	50A26800103602	self-driving screw
126	5021061000183012A	lamp shade
127	502106100023A	indication light
128	50A26800303101	heteromorphosis screw
129	5021062004090001B	upper handle
130	50A26800102101	self-driving screw
131	5021061001570002A	left handle plug-in
132	502106800003B	right plug-in spring
133	5021062003030002N	start handle
134	502106100311A	handle sheath
135	50A26800104601A	self-driving screw
136	5021061001113201N	wave washer
137	5021061001603201B	right bracket of driving pole
138	5021061001623201A	washer of pulling bracket
139	5021061001803201B	self-propelled cord block

No.	ID zboží	Název
140	5021061001613201A	cover board of pulling pole
141	5021061001593201B	left bracket of driving pole
142	5021062004190001N	driving pole
143	5021041001160001A	knob pressing board
144	502109800022C	spring
145	5021041001150182A	mulching kit button
146	5021061000930001A	mulching kit
147	5021071000050001	handle of grass catcher
148	5021071000520001A	grass catcher
149	502100X04474	rear board ass'y
150	502107200024C	grass catcher bracket
151	5021071000080002	level indicator
152	50A26800103202	self-driving screw
153	5021077000462147A	grass catcher
154	502103200002A	spanner
155	50A26800702101	washer