

# MODEL 309000x8NA

# REPAIR PARTS CHASSIS & HOOD




# MODEL 309000x8NA

# REPAIR PARTS CHASSIS & HOOD

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Seat	690566	23	Screw	6x111
2	Hood	1401027E700	24	Screw	26x253
3	Washer	17x47	25	Screw	26x263
4	Bolt, Wing	1001054	26	Rod, Hood Prop	1401110
5	Bolt, Carriage	2x53	27	Spring, Seat Deck	1401282
6	Bracket, Hinge	1401036E701	28	Bracket, Prop Rod	1401056E701
7	Bolt, Shoulder	9x29	29	Screw	26x201
10	Rod, Battery	1401113	30	Nut, NY-Lock	15x116
11	Nut, Flange	15x84	31	Control, Throttle	1401248
12	Plate, Rear	1401025E701	32	Cover, Detent (Black)	1401084
13	Screw	26x249	33	Bolt, Shoulder	9x47
14	Plate, Hitch	1401050E701	36	Footmat, Left (Black)	1401229
15	Cover	1401086	37	Footmat, Right (Black)	1401228
16	Screw	26x263	39	Frame	1401256E701
17	Tray, Battery	1401076E701	40	Deck, Seat	1401026E700
18	Nut, Flange	15x79	41	Bumper	94744
19	Washer	17x37	42	Nut	15x116
20	Pin, Cotter	30x20	43	Screw	25x2
21	Cap, Fuel Tank	92317	- -	Book, Instruction	F-030603C
22	Tank, Fuel	1401240			

# MODEL 309000x8NA

# REPAIR PARTS MOTION DRIVE




# MODEL 309000x8NA

# REPAIR PARTS MOTION DRIVE

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Engine *	----	38	Clutch Arm Assembly	1401128
2	Bolt, Hex	1x134	39	Ring, Retainer	11x7
3	Shield Assembly, Heat	1401207	40	Pulley, Drive	1401077
4	Lockwasher	18x32	41	Bolt, Carriage	2x53
5	Screw	25x2	42	Bolt, Shoulder	9x73
6	Muffler	1401251	43	Pulley, Idler	690410
7	Gasket, Muffler	91309	44	Belt, Motion Drive	37x110
8	Spring, Extension	165x75	45	Pulley, Split Stack	1401066
9	Spring, Extension	165x148	46	Washer, Star	19x35
10	Nut	15x88	47	Washer	17x170
11	Screw	26x249	48	Bolt, Hex	1x140
12	Bracket, Left Transaxle	1401042	49	Washer	17x102
13	Nut, Flange	15x84	50	Arm, Rear	1401031E701
14	Cover, Pedal	21544	51	Bracket, Rear Hanger	1401039
15	Pin, Cotter	31x4	52	Pin, Threaded Shoulder	94067
16	Washer	17x53	53	Bolt, Hex	1x155
17	Pin, Cotter	30x20	54	Bolt	1x120
18	Pedal Assembly	1401127E701	55	Bracket, Torque Reactor	1401051E701
19	Rod, Parking Brake	1401112	56	Screw	6x105
20	Grip, Parking Brake Rod	91079	57	Washer, Shift Yoke	17x38
21	Frame	1401256E701	58	Support, Frame	1401260E701
22	Grip, Shift Lever	92697	59	Yoke, Shift	1401093
23	Nut, Adjusting	1401148	60	Washer	17x148
24	Link, Shift	1401122	61	Transaxle, Peerless *	----
25	Lever, Shift	1401111	62	Bracket, Transaxle	1401268
26	Bracket, Lift Pivot	1401032	63	Spacer	690369
27	Spring, Extension	165x147	64	Washer	17x160
28	Bolt, Shoulder	9x73	65	Key, Square	56534
29	Bracket, Pivot	1401043	66	Spacer, Rear Wheel	1401103
30	Guide, Short Belt	1401104	67	Wheel, Rear -15"	1401290
31	Guide, Long Belt	1401105	68	Cap, Hub	94618
32	Plate, Belt Guide	1401057	69	E-Ring	11x3
33	Bolt	25x7	70	Washer	17x195
34	Nut, Flange	15x79	72	Lock, Screw	92378
35	Bracket, Support	1401059	73	Nut	15x43
36	Nut, Adjusting	94815	74	Nut	15x98
37	Rod, Clutch	1401078			

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

\*\* For information on Replacement Parts see the Central Parts Distributor in your area.




# MODEL 309000x8NA

# REPAIR PARTS STEERING

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Wheel, Steering (Black)	95185	19	Washer	17x118
2	Insert, Steering	711326	20	Gear, Pinion	1401099
3	Console, Low (Black)	1401044	21	Bolt, Hex	1x146
- -	Console, Low (Grey)	1401045	22	E-Ring, Retainer	11x28
4	Screw	26x270	23	Pin, Cotter	30x35
5	Bearing, Upper Steering	1401090	24	Retainer, Spring	094131
6	Tube, Steering (Black)	1401226	24	Retainer, Spring	094131
--	Tube, Steering (Grey)	1401227	25	Rack, Steering	1401046
7	Shaft, Steering	1401100	26	Washer	17x201
8	Support, Steering	1401055E701	27	Bracket, Axle Front	1401060
9	Screw	26x249	28	Washer	17x157
10	Bolt, Shoulder	9x67	29	Axle & Spindle Assembly	1401250
11	Bearing, Lower Steering	1401098	30	Bracket, Support	1401059
12	Roller	1401102	31	Nut, Flange	15x118
13	Plate, Gear Mounting	1401058	32	Wheel, Front	1401289
14	Link, Drag	1401123	33	Washer	17x197
15	Nut, Flange	15x84	34	Washer	17x157
16	Washer	17x104	35	Cap, Hub	94618
17	Nut, Flange	15x88	36	Bolt	25x3
18	Bolt, Hex	1x111	37	Washer	17x146

\* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.



# MODEL 309000x8NA


# REPAIR PARTS MOWER HOUSING SUSPENSION

<b>Key No.</b>	<b>Description</b>	<b>Part No.</b>	<b>Key No.</b>	<b>Description</b>	<b>Part No.</b>
1	Grip, Lift Lever	92697	17	Nut, Flange	15x79
2	Lever, Lift	1401117	18	Nut, Flange	15x84
3	Spring, Extension	165x154	19	Spring, Leaf	1401147
4	Pad, Friction	94137	20	Hanger, Front	1401040
5	Washer	17x45	21	Lever, PTO	1401116
6	Wingnut	95004	22	Screw	26x263
7	Link, Lift	1401033E701	23	Grip, PTO	94198
8	Tube, Spacer	1401096	24	Bracket, PTO	1401199E701
9	Pin, Hair	31x4	25	Bolt, Shoulder	9x42
10	Bolt, Carriage	2x93	26	Spring, Extension	165x157
11	Bracket, Front Hanger Pivot	1401030E701	27	Spring, Extension	165x92
12	Pin, Front Hanger	1401118	28	Bolt, Shoulder	9x58
13	Screw	26x249	29	Nut	15x84
14	Arm Assembly, Lifter	1401262E701	30	Plate, Reinforcement	1401260
15	Washer	17x206	31	Screw	26x267
16	Screw, Guide	93349			



# MODEL 309000x8NA


# REPAIR PARTS MOWER HOUSING



# MODEL 309000x8NA

# REPAIR PARTS MOWER HOUSING

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Belt, Blade Drive	37x111	32	Bolt, Shoulder	9x73
2	Pulley, Input	1401092	34	Pin, Cotter	30x20
3	Locknut	15x121	35	Arm Assembly, Brake	1401185
4	Nut, Flange	15x98	36	Link, Idler Arm	1401119
5	Pulley, Idler	1401252	37	Bolt	25x7
6	Nut, Flange	15x84	38	Bracket, Brake Mounting	1401052
7	Arm, Rear	1401031	39	Spacer, Jackshaft	1401094
8	Nut, Flange	15x79	40	Plate, Idler Mounting	1401259 Z
9	Bolt, Shoulder	9x58	42	Washer	19x45
10	Link, Lift	1401033	43	Bolt, Carriage	2x94
11	Washer	17x102	45	Bolt, Carriage	2x53
12	Pin, Hair	31x4	47	Housing, Blade	1401028
13	Pin, Threaded Shoulder	94067	48	Hinge, Mulching Cover	1401106
14	Bracket, Left Rear	1401047	49	Nut, Flange	15x88
15	Bracket, Right Rear	1401235	50	Nut, Speed	28x76
16	Plate, Adjustment	1401038	51	Wingnut	14x86
17	Pad, Friction	94137	52	Bolt, Carriage	2x74
18	Washer	17x45	53	Rod, Chute Deflector	91767
19	Wingnut	95004	54	Cap, Push	28x23
20	Spring, Left Torsion	166x43	55	Cover, Mulch (Black)	1401080
21	Spring, Right Torsion	166x42	--	Cover, Mulch (Grey)	1401217
22	Tube, Spacer	1401095	56	Mandrel Housing	1401275
23	Bracket, Deck	1401037	57	Adapter, Blade	1001035
24	Hanger, Front	1401040E701	58	Blade	1401079
26	Shaft, Splined	1401065	59	Washer, Cup	17x166
27	Arm Assembly, Idler	1401258E701	60	Washer	17x165
28	Bolt, Shoulder	9x73	61	Nut, Blade Mount	15x100
29	Washer	17x47	62	Deflector, Chute (Black)	1401081
30	Spring, Extension	165x157	--	Deflector, Chute (Grey)	1401218
31	Spring, Torsion	166x46	63	Washer	17x120



<b>Key No.</b>	<b>Description</b>	<b>Part No.</b>
1	Harness, Chassis Wire	250x115
2	Switch, Ignition	1401149
	Key, Ignition	327349
	Nut, Hex	
	Cap, Ignition	
3	Switch, Limit	1001575
4	Fuse	54212
	Holder, Fuse	407078
5	Solenoid	94613
	Screw, Mounting	26x229
	Locknut	15x116
6	Cable, Battery Ground	24x37
	Screw, Ground Cable	
7	Battery	92739
	Bolt, Carriage	2x82
	Wingnut	14x79
8	Switch, Seat Sensor	94159
9	Cable, Red Batery	24x24
	Boot, Positive Terminal	690604