







# WB 466 SCM

r.v. 2020





**WEIBANG**®

# 2 Main Body




<b>Part 2 - Main Body Spare parts</b>		
<b>No.</b>	<b>ID Zboží</b>	<b>Název</b>
1	GM46A040000000/40	Bumper
2	0202006000	Lock Nut - M6
3	0102006018	Bolt - M6x18
4	GM46D010000000/49	Chassis
5	0102006012	Bolt - M6x12
6	5320114020/01	Bearing Holder
7	GM46A000000050	Trailing Flap
8	GM46A000000060/02	Pivot - Trailing Flap
9	0104006016	Screw - M6x16
10	GM46A000000020/01	Graduator
11	0106004010	Screw - St4.2x10
12	GM46A000000040	Rear Shield
13	GM46A000000070/01	Spring - Connecting Rod
14	GM46A000000030/40	Connecting Rod
15	5320333010	Check Ring
16	0301010000	Washer - M10
17	0104005012	Screw - M5x12
18	AVSA000000040/22	Tooth Disc
19	0202005000	Lock Nut - M5

# 3 Blade system




<b>Part 3 - blade assembly Spare parts</b>		
<b>No.</b>	<b>ID Zboží</b>	<b>Název</b>
1	GM53A050000000	Engine Base
2	GM53A000000070/02	Bolt
3	5320120012	Belt - V10x780
4	4510401010	Key
5	0105006006	Screw - M6x6
6	5020402070/02	Engine Pulley
7	GM53A000000050/02	Adaptor
8	6006/2RS	Bearing
9	GM53A000000120	Wave Washer
10	GM53A000000010	Axle Protection Bracket
11	0204014000	Lock Nut - M14
12	GM53A000000060/04	Spacer
13	GM46A000000010/22	Blade
14	4510407010/04	Spring Washer
15	XYJ-200011	Blade Bolt

# 4Front Axle



<b>Part 4 - front axle assembly Spare parts</b>		
<b>No.</b>	<b>ID Zboží</b>	<b>Název</b>
1	5310214010	Wheel Cap
2	0102008016	Bolt - M8x16
3	0401008000	Spring Washer - M8
4	0301008000	Washer - M8
5	4510210010/40	Wheel
6	5310213010	Bearing
7	5310211010/02	Spacer
8	5310210010/02	Spacer
9	GM46A020100000/01	Front Axle
10	5310209010	Spherical Bearing
11	GM53A020000010	Scraper


# 5 Rear Axle





<b>Part 5 - rear axle assembly Spare parts</b>		
<b>No.</b>	<b>ID Zboží</b>	<b>Název</b>
1	5310214010	Wheel Cap
2	0102008016	Bolt - M8x16
3	0401008000	Spring Washer - M8
4	0301008000	Washer - M8
5	4820305020/40	Rear Wheel - 9"
6	5310213010	Bearing
7	5310211010/02	Spacer
8	5310210010/02	Washer
9	GM46A030100000/01	Rear Axle
10	1301009000	E-Clip - M9
11	5020311010/04	Spacer
12	5320326010P	Bearing
13	HQ000100020	Drive Pinion - R/H
14	HQ000100050	Ratchet
15	4520308010	Dustproof Shield
16	Y065321	Right Bearing Sheath Assembly
17	5320325020/02	Right Bearing Sheath
18	5320327010	Dust Seal
19	1001020000	Circlip - M20
20	5020310010/02	Rear Transmission Partition
21	5320328010	Spherical Bearing
22	HQ000100060	Check Holder
23	Y20466M	Transmission Assembly
24	4820317010	Spring
25	4540318010	Pulley
26	1001012000	Circlip - M12
27	GM48S010000010	Spacer
28	0101006020	Bolt - M6x20
29	5360310010/40	Adjustment Lever
30	5360311010/22	Spring Of Adjustment Lever
31	0101006014	Bolt - M6x14
32	0113005008	Screw - M5x8
33	0202006000	Lock Nut - M6
34	Y065320	Left Bearing Sheath Assembly
35	5320324020/02	Right Bearing Sheath
36	HQ000100010	Drive Pinion - L/H
37	HQ000100040	Spring - Drive Pinion
38	HQ000100030	Pin - Drive Pinion
39	GM53A020000010	Scraper
40	R8-2RS	Bearing
41	1401025015	O-ring

# 6 Handle And Controls



<b>Part 6 - handle bar assembly Spare parts</b>		
<b>No.</b>	<b>ID Zboží</b>	<b>Název</b>
1	GM46D050000010/49	Handle
2	GM56E010000081	Handle Sheath
3	5020506030S/40	Clutch Lever
4	5020503020S/40	Opç Lever
5	GM46E050000030	Throttle Control Box Upper Cover
6	0202006000	Lock Nut - M6
7	0106003013	Screw - ST2.9x13
8	5380510010	Throttle Control Grip
9	GM46E050100000	Throttle Control Bracket
10	0108006040	Screw - M6x40
11	0108006050	Screw - M6x50
12	GM46E050000040	Throttle Control Box Lower Cover
13	0113040018	Screw - ST4x18
14	LH194-1195	Clutch Cable
15	BS120-1140	Brake Cable
16	YM72-970-A	Throttle Cable
17	ZD8/200	Cable Tie - 8x200mm
18	0301006000	Washer - M6
19	4510511010/01	Hook - Starter Rope
20	0801008025	Axis Pin - 8x25
21	GM56A100400000	Lock Lever
22	GM48S000000100	Connecting Bolt
23	4510114030	Fix Cap
24	GM56A100000040/04	Spacer
25	GM56A100000050/01	Spacer
26	GM48S030200000	Tooth Disc Kit
27	0203008000	Lock Nut-M8