


Model: WBLT567SLC
Service code: WBLT567SLC2311
Handle and controls




Weibang WB LT 567 SLC
r.v. 2025

Part1 Handle and controls		
No.	ID Zboží	Název
1	1371000340	Clutch handle
2	1371000744	Upper handle
3	GM56E010000082	Handle sheath
4	76G506000	Handle wear sleeve
5	1371000040	Blade disc handle
6	0108006035	Screw - M6*35
7	0202006000	Lock nut - M6
8	1371001002	Spring for Location-limited Plate
9	1371001149	Location-limited Plate
10	4510511010/01	Cable hook
11	0301006000	Flat washer - φ6
12	5360506011	Bolt
13	0301005000	Flat washer - φ5
14	0202005000	Lock nut - M5
15	5380508010	Speed regulating grip
16	0106003013	Screw - ST2.9*13
17	13710012	Speed regulating bracket
18	0108006060	Screw - M6*60
19	5380510010	Throttle grip
20	5380512010	Throttle bracket
21	0108006045	Screw - M6*45
22	0104005012	Screw - M5*12
23	0106005018B	Screw - M5*18
24	KL00-LC1P70	Air Filter Base
25	13710015	Cover


Part1 Handle and controls		
No.	ID Zboží	Název
26	KL02-LC1P70	Air filter screen
27	KL04-LC1P70	Air Filter Sponge
28	KL05-LC1P70	Cable Upper Cover
29	5020501040S	Speed regulating Box Lower Cover
30	0113040018	Screw - PT4*18
31	13710016	Speed regulating cable
32	13710002	Blade disc cable
33	13710017	Clutch cable
34	13710018	Throttle cable
35	GM56A100400000	Quick release handle
36	0801008025	Pin - 8x25
37	4510114030	Fix Cap
38	GM56A100000030/02	Connecting Bolt
39	GM56A100000040/04	Spacer
40	GM56A100000050/02	Spacer
41	GM48S030200000	Outside Tooth Disc Kit
45	13710023	Inner Tooth Disc Kit
46	0203008000	Lock nut - M8
47	1371001922	Lower handle
48	0102008025	Bolt - M8*25
49	0301008000	Flat washer - φ8
50	0202008000	Lock nut - M8
51	05011P6010	Pin - 1.6*10
52	0201006000	Nut - M6

Model: WBLT567SLC
Service code: WBLT567SLC2311
Mowing part




Part2 Mowing part		
No.	ID Zboží	Název
1	0101008020	Bolt - M8*20
2	0401008000	Spring washer - $\varnothing 8$
3	0302008000	Big washer - $\varnothing 8$
4	1101005020	Key - 5*5*20
5	1372000202	Pulley
6	6203-2RS	Bearing
7	1372000602	Shaft
8	4820104011	Screw - M6*16
9	0302006000	Big washer - $\varnothing 6$
10	1372000702	Belt frame
11	0102006040	Bolt - M6*40
12	0102006016	Bolt - M6*16
13	0102006030	Bolt - M6*30
14	13720008	Bearing base
15	0301006000	Flat washer - $\varnothing 6$
16	0202006000	Lock nut - M6
17	13720009	guard
18	1372001040	Bumper
19	0401006000	Spring washer - $\varnothing 6$
20	0101006016	Bolt - M6*16
21	13720015	Protective plate
22	0102005025	Bolt - M5*25
23	1372001744	Connecting rod
24	1372002004	Twine knife
25	0301005000	Flat washer - $\varnothing 5$
26	0202005000	Lock nut - M5
27	1372003322	Upper protective bowl
28	13720024	splint
29	13720026	TRIMMER LINE
30	1372002722	Protecting cover
31	1372000002	Spacer sleeve
32	13720028	Dust ring
33	0113040014	Screw - PT4*14
34	1372002902	splint
35	6202-2RS	Bearing
36	13720030	Lower protective bowl
37	0301010000	Flat washer - $\varnothing 10$
38	0401010000	Spring washer - $\varnothing 10$
39	0101010040	Bolt - M10*40
40	13720031	Plug screw

Model: WBLT567SLC
Service code: WBLT567SLC2311
Rear axle




Part3 Rear axle		
No.	ID Zboží	Název
1	YLT56A001	Transmission
2	0202006000	Lock nut - M6
3	0301006000	Flat washer - $\varphi 6$
4	KFL001-8	Bearing
5	1373000502	Step bolt - M6*20
6	06B0146B1	Chain
7	0701004020	Pin - 4*20
8	1373000602	Sprocket A
9	0102008020	Bolt - M8*20
10	0202008000	Lock nut - M8
11	1373000022	Wheel bridge

Model: WBLT567SLC
Service code: WBLT567SLC2311
Chassis



Part4 Chassis		
No.	ID Zboží	Název
1	LC1P70FC/L1030	Engine
2	180020920-0001	Air filter
3	KL03-LC1P70	Air filter tube
4	1374000044	Chassis
5	0102006016	Bolt - M6*16
6	0102008020	Bolt - M8*20
7	1374000802	Frame
8	5320115010	Screw
9	4510401010	Key
10	1374000902	Engine big pulley
11	1374001202	Engine small pulley
12	5310414010/04	Spring
13	5310415020	Central - 3/8-24*30
14	1374001402	Tensioner spring
15	1374001502	Cable bracket
16	0301006000	Flat washer - φ6
17	0202006000	Lock nut - M6
18	1374001602	Flat washer
19	1374001702	Tensioner fixing plate
20	1374001902	Tensioner fixing sleeve
21	0202008000	Lock nut - M8
22	1374002002	Tensioner axle sleeve
23	13740021	Tensioner pulley
24	SW8012/04	Tensioner pulley
25	6200-2RS	Bearing
26	0901030000	Circlip - 30
27	1374002202	Tensioner spacer sleeve
28	1374002302	Tensioner plate
29	13740024	Belt
30	3L190K	Belt
31	4820114010	Tensioner spring
32	1374002502	Pulley mounting plate
33	GM56A020000080/02	T-shaped sleeve
34	GM56A020000090	Tensioner bolt
35	GM56A020000030/02	Spacer sleeve 1
36	61800-2RS	Bearing
37	1001024000	Circlip - 24
38	GM56A020000040/02	Pulley connecting sleeve
39	GM56A020000060/02	Spacer sleeve 2
40	GM56A020000010/06	Upper upper pulley piece
41	GM56A020100030	Check ring
42	13740002	Middle pulley piece
43	GM56A020100020	Spring
44	13740003	Middle lower pulley piece
45	0202010000	Lock nut - M10
46	4820104011	Screw - M6*15
47	13740026	Baffle
48	13740027	Lower shield
49	1374002802	Hanging rod
50	13740029	Hanging skin
51	180130289-0001 +180130290-0001	Air filter element
52	5310112020/02	Washer

Model: WBLT567SLC
Service code: WBLT567SLC2311
Axle



Part5 Axle		
No.	ID Zboží	Název
1	13750000	Wheel cap
2	0202008000	Lock nut - M8
3	0303008000/02	Big flat washer
4	13750001	Wheel
6	1001017000	Circlip - 17
7	0301016000	Flat washer - $\varnothing$ 16
8	13750003	Plastic bearing
9	0301008000	Flat washer - $\varnothing$ 8
10	KFL006	Bearing
11	76EA12000A1/02	Step bolt - M8*25
12	1001030000	Circlip - 30
13	0202006000	Lock nut - M6
14	1375000402	Sleeve B
15	13750005	Shaft B
16	LT56AE07000	Pawl spring
17	1375001702	Pawl
18	1375001802	Pawl positioning plate
19	1375001902	Pawl clamp plate
20	1375002002	Sprocket B
21	13750014	Shaft A
22	1375001302	Sleeve A
23	0101006045	Bolt - M6*45
24	13750021	Axle assembly